



ENGINE MALFUNCTION CHECK PROCEDURE | MDE4/25 CONNECTION CONTROL |

MDF 4/25 CABLES

A1 USB/A "adapter" cable to PC connection [male-to-female]

A2 USB/A "adapter" cable power supply connection [male-to-female]

B1 PC connection cable

B2 Power supply cable

CHECKS PROCEDURE

At each step, check the functionality of the trainer. If the problem persists, proceed to the next step.

STEP I

Replace the power supply with an equivalent, one with at least $5\,\mathrm{V}$ ($2\mathrm{A}$)

STEP II

Swap A2 cable with A1, then insert A1 adapter cable instead of A2

STEP III

Swap cables B2 and B1



WARNING

Be careful to **NOT** connect the PC to the mini-USB socket dedicated to the power supply (don't connect the power supply to the mini-USB socket dedicated to the PC).